

## EC1 Beholder Gimbal for DSLR and Mirrorless Cameras

## **ONE SHEET**

### **Overview**

The Beholder EC1 is designed specifically for professional filmmakers looking for a single handheld stabilizer for a large range of medium and small cameras. The Beholder EC1 is lightweight, easy to use, and can be carried in the supplied case or a small photographer bag.



EC1 | EC1 Beholder Gimbals for DSLR and Mirrorless Cameras | UPC Code: 847983019465

# **Special Features**

- 3-Axis hand-held gimbal stabilizer with 360° rotating motor
- Designed for DSLR & mirrorless cameras up to 4.5 lbs (2041g)
- Stabilized with a 32-bit controller and a 12-bit encoder system
- Adaptive PID algorithm produces reliable stability and efficient battery life
- Battery operating life of up to 20 hours with 3 rechargeable 18650 batteries
- 4 Modes of operation with Auto-Inversion and an OLED status display
- With an innovative manual point and lock composition adjustment feature
- Quick-release baseplate with a tool-less balancing system
- 2x 1/4-20 Accessory mounts & a 3/8-16 tripod mount integrated into the handle

# kan

## **Recommended For**

- Videographers
- Camera Operators
- Cinematographers
- **DSLR Cameras Mirrorless** Cameras



www.facebook.com/ikanseeit



www.twitter.com/ikancorp



www.vimeo.com/ikancorp



www.youtube.com/ikancorp



#### 360° Motors

The 3-Axis gimbal features three 360° rotating brushless motors that give you a limitless range of motion.

#### **Designed for Various Cameras**

With a payload range of 2-4.5 lbs, the EC1 has the ability to stabilize a wide range of today's popular DSLR and mirrorless cameras. Sony a6300, Sony a7SII, Panasonic GH4, and the Canon 5D Mark III are just a few cameras that the EC1 can handle.

#### **Advanced Stabilization**

Using a 32-bit controller with a 12-bit encoder, the EC1 uses an adaptive PID algorithm to produce a reliably efficient handheld stabilizer.

#### **Lock Mode**

In Lock Mode, the Yaw, Pitch, & Roll axis work together to keep the camera pointed in one direction. The camera's composition will stay the same no matter how you move the handle.

#### **Point & Lock**

Quickly lock your camera into any position by manually pointing and holding it in any direction. After a few seconds, the camera will lock and hold its position until it is reset back to default.

#### **Multiple Follow Modes**

The EC1 features 3 different follow modes. In Yaw-Axis Follow Mode, the EC1 will only follow your Pan movements. In Pitch and Yaw-Axis Follow mode, the EC1 will follow your Pan and Tilt Movements. Finally, the 3-Axis Follow Mode gives you full control allowing you to Pan, Tilt, and Roll.

#### **Auto Inversion**

Switch to Inverted Mode at any time by simply flipping the handle over the camera. Inverted Mode can be operated in conjunction with any of the Lock and Follow Modes.

#### **OLED Status Display**

A display screen located on the back of the handle conveniently provides you with information on the battery life and operating mode.

#### Easy-to-Use

With a newly designed quick-release baseplate system, the EC1 is easy to balance without the need of any tools.

#### Multiple Mounting Points

The EC1 handle comes with two 1/4-20 mounts that are perfect for mounting accessories such as a light, microphone, or monitor. A 3/8-16 thread located on the bottom allows you to securely mount the EC1 to a tripod, jib, or dual handle support system such as the Ikan DGH.

## Features you need, Prices you want.

Specifications	
Battery Operating Time	Approx 8-10 Hrs
Stand-by Battery Time	Approx 20 Hrs
Battery Charging Time	Approx 3-4 Hrs
Battery Type	3x 3.7v Li-lon 18650
Camera Compatibility	Most Mirrorless & DSLR Cameras
Load Capacity	2000g
Working Temperature	-10°C to 70°C
Working Angles	Pan: 360°
	Roll: 360°
	Pitch: 360°
Tripod Mounting Thread	3/8"-16
Accessory Mounting Threads	1 x 1/4"-20
Dimensions	360 x 79 x 184 mm

Shipping Specs	
Shipping Dimensions	15.75 x 8.5 x 3.75 ln.
Shipping Weight	6 lbs

#### What's Included

- 1 x Instruction Manual
- 1 x Travel Case
- 1 x Travel Case Shoulder Strap
- 3 x 18650 Batteries
- 1 x Micro USB AC Adapter
- 1 x EC1 Gimbal Stabilizer
- 1 x Battery Cap with 3/8-16 Mount (Pre-Assembled)
- 1 x Battery Holder (Pre-Assembled)
- 1 x Quick Release Plate (Pre-Assembled)
- 1 x 1/4-20 Camera Screw (Pre-Assembled)

#### **Essential Accessories**

DGH Dual Grip Handle & Tray for Beholder Gimbal Stabilizers
EXT-K01 Beholder Joystick Extensions for Camera Gimbals (1m)

MC-90 Carbon Fiber Monopod (E-Image)

MS-E002 Battery Holder

ICH-SC4 4 Battery Universal Smart LCD Charger

**IB-18650-26** 18650 3.7V Li-lon Battery





