

False Color Key

Use the adjustable warning to prevent over exposures in your video

Use the 70 - 80 IRE indicators to assist in setting exposure for white objects.

Use the 56 IRE indicator to assist in setting exposure for skin tones

Use the 45 IRE indicator in assist in setting exposures when using a gray card

Use the adjustable warning to prevent under exposures in your video

