



## **MOTION CONTROLLER / MD2 PAIRING INSTRUCTIONS**

To pair the motion controller with the MD2, use the following steps:

1. Turn the MD2 and Motion Controller off.
2. Press and hold the mode button and joystick simultaneously on the right control grip of the MD2.
3. While still holding the mode button and joystick down, power on the MD2. (The indicator light will begin to flash blue)
4. Release the mode button and joystick. Grab the Motion Controller.
5. Press and hold the mode button and joystick simultaneously on the right control grip of the Motion Controller.
6. While still holding the mode button and joystick down, power on the Motion Controller. (The indicator light will begin to flash blue. The MD2 and Motion Controller will begin to pair)
7. The indicator light on the MD2 and Motion Controller will turn solid blue indicating that pairing was completed successfully.
8. Power off the MD2 and Motion Controller.

The MD2 and Motion Controller are now officially paired together. Simply turn on the Motion Controller when you desire to use it. Pairing has been saved to their memory, and they will now recognize each other.

If you have further questions, please contact Ikan Support at

*[support@ikancorp.com](mailto:support@ikancorp.com)*

or

713-272-8822 | 9am-6pm CST