

# Beholder Mirrorless Camera Gimbal

### **ONE SHEET**

### **Overview**

The Beholder Gimbal MS1 is a 3-axis handheld camera stabilizer designed for point-and-shoot and mirrorless cameras to achieve smooth, stable footage. The Beholder uses brushless gimbal motors to stabilize movement on tilt-and-roll axes and provide incredibly smooth image capture while shooting handheld, while walking, or in any situation in which the camera is moving.

The MS1 can support up to 1.9 pounds (860 grams) of camera. A number of cameras are well-suited for the MS1 including the Sony a7S, RX-100 and NEX series, Panasonic GH4, Samsung NX500, and Blackmagic Pocket Cinema Camera.

The gimbal's ¼" – 20 thread mount at the bottom of the handle is perfect for attaching an articulating arm that serves a screen for monitoring / recording (e.g., a small monitor or smartphone), or for mounting the MS1 to a monopod, tripod or slider. The built-in 5-way joystick control offers complete command over pan/tilt and mode choice. Select from "Follow," "Lock," and adjust Pan-and-Tilt.

A USB port on the handle can be used to power a small LED light or your smartphone. Included with the stabilizer is a quick-release balance plate, an offset camera mount, an onboard USB LED Light, a USB cable for charging, and a travel case.



MS1 | Beholder Mirrorless Camera Gimbal | UPC Code: 847983014941

# **Special Features**

- 3-Axis Stabilized Gimbal System (pan, tilt, and rotate)
- All-Aluminum Construction
- No tools required for balance
- Easy mount and balance with Quick-Release Balance plate
- Gesture Control System
- Pan and Tilt Control Stick
- Follow and Lock Modes
- Supports BMPCC, GH4, A7 series, Sony NEX series, etc.
- ¼" 20 thread mount



## **Recommended For**

- Portable Cinematography
- Mirrorless Cameras
- DSLRs (under 1.9 Lbs)



www.facebook.com/ikanseeit



www.twitter.com/ikancorp



www.vimeo.com/ikancorp



www.youtube.com/ikancorp



# Features you need, Prices you want.

### **Supports Multiple Devices**

The Beholder gimbal is perfect for small DSLR and mirrorless cameras such as Sony's a7S, RX-100 & NEX Series, Panasonic GH4, Samsung NX500, and Blackmagic Pocket Cinema Camera.

#### **Quick Release Balance Plate**

Easily mount and balance your camera with the quickrelease balance baseplate. Tool-less adjustments are easily made for lens changes.

#### **Pan & Tilt Control Stick**

The pan-and-tilt "joystick" puts control at your fingertips. Greater movement is at your command. Shooting angles range up to approximately 45° roll and 90° Tilt (off center).

#### **Multiple Modes of Operation**

Choose your mode of operation based on the desired shot. Follow or Lock Mode.

#### **All-Aluminum Construction**

Durable, lightweight aluminum build.

#### **Easily Customizable**

Build a pro shooting rig for your shooting style. A convenient 1/4"-20 thread hole allows for mounting a monitor, microphone or light.

Use the gimbal with a monopod to get jib-like moves. Keep your camera ready to shoot on a tripod.


### **USB Power Options**

The USB port on the handle can be used to charge or power your smartphone, GoPro camera or other USB-powered devices. This is convenient if your camera has a Wi-Fi "Live" mode and you can send the signal to your smartphone.

#### What's Included

- 1 x Stabilizer
- 1 x Battery Holder
- 3 x 18650 Batteries
- 1 x Battery Cap
- 1 x Quick Release Plate
- 1 x Micro USB Cable
- 2 x 1/4"-20 Screw
- 1 x Adapter Plate

WARNING! This product comes from the factory tuned and ready to use. It is NOT meant to be user-serviceable, accessing and changing software settings and/or tuning settings will void warranty.



#### **Optional Accessories**

MA207 7" Articulating Arm MA211 11" Articulating Arm

MA211-R 11" Articulating Arm w/ Single Rod Mount

**HD-STND** Heavy Duty Light Stand

5" HDMI Monitor w/ Sunhood & E6 Battery Plate VL5e

iLED-MA Micro Flood Light

iLED-MS Micro Spot On-Camera Light





