

# QUICK START GUIDE / VH7 7" HDMI LCD MONITOR

## INTRODUCTION

Thank you for purchasing the ikan VH7 LCD Monitor. We know that you will be satisfied with our "V" series monitors. Please visit [www.ikancorp.com](http://www.ikancorp.com) for more information on our current and future products including our award-winning fluorescent studio lights and light accessories.


## PACKAGE INCLUDES

- VH7 LCD Monitor
- AC Power Adapter
- Camera Shoe Mount
- Battery Adapter (check one): [ BP2T-S ] [ BP2T-SU ] [ BP2T-C ] [ BP2T-P ]
- VGA Cable
- Remote Control
- 2 x Composite Female RCA Cable





## MONITOR DIAGRAMS

Front view



Back view



## BUTTON FUNCTIONS

- 1 Volume Buttons**  
Decreases and increases volume as well as toggle through menu.
- 2 Menu Button**  
It is to display brightness, contrast, phase, clock, H position, V position, language, auto, reset, volume, exit.
- 3 Input Button**  
Video selection switch AV1, AV2, VGA, HDMI
- 4 ASPECT Selection Button**  
Aspect: 16:9, 4:3, Full
- 5 Power Button**  
Turns monitor on and off

## CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.