

IDMX36

Field-Optimized LED Studio Light w/ DMX Control

QUICKSTART GUIDE



What's included

- IDMX 36 Light
- AC Adapter
- Gel Frame

Checked by

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.

IDMX36

Field-Optimized LED Studio Light w/ DMX Control

INTRODUCTION

Thank you for purchasing the ikan IDMX36. The IDMX36 is extremely easy to use and will quickly become an integral part of your production needs. For more information on the IDMX36 and many other innovative ikan products, please visit our website: www.ikancorp.com.

PACKAGE CHECK LIST

- ID36 Light
- AC Adapter
- Gel Frame

GETTING STARTED



1. Power on and off the light using the Main Power switch.
2. Increase amount of light with the Dimmer Knob clock-wise.
3. Decrease the amount of light with the Dimmer Knob counter clock-wise.
4. The IDMX36 can also be powered by the included AC adapter.
5. For controlling the light locally, Pin 11 must be turned on, and the rest of the lights must be turned off.

ADJUSTING THE BRIGHTNESS

The Dimmer Knob on the back of the light allows you to adjust the intensity of the light. Adjust the intensity of the light by turning the Dimmer Knob clock-wise to increase the intensity and counter clock-wise to reduce it.

SPECIFICATIONS:

- Power: 30w
- AC100 voltage of 120V/60Hz
- AC or DC power options available
- Dimensions 11" x 4" x 16"



CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.