
IDMX500

500 LED DMX Studio Light QUICKSTART GUIDE



What's included

П	NΛX	500) I (iaht
	 VIZ		, .	

- □ AC Adapter + Power Cord
- ☐ Yoke
- ☐ Handle (2)
 - Stand Adapter

	1
Checked by	

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.



IDMX500

500 LED DMX Studio Light QUICKSTART GUIDE

GETTING STARTED

- 1. Connect the included AC Adapter to power the IDMX 500 light.
- 2. Turn the light on / off with the Power Switch.
- 3. Control the amount of the light with the Touch Screen. Adjust the intensity of the light by touching the up or down arrows to increase or decrease the intensity.
- 4. DMX Control can be used by 512 DMX Board.

