IFJ57/6-SP-2P1-KIT

Kit w/ 2 IFD576 LED Spot Lights w/ AB & V-Mount Plates

QUICK START GUIDE



What's Included

- □ 2 x IFD576-SP
- □ 2 x Light Stands
- □ 1 x Light Bag
- □ 1 x Stand Bag

Additional Quickstart Guides

□ IFD576-SP LED Light QSG





713.272.8822 © 2015 ikan Corporation. All rights Reserved

IFD576-SP 576 Daylight Spot LED Light




What's Included

- \Box 1 x Diffuser
- □ 1 x IFD576 Light
- \Box 1 x Power Supply
- □ 1 x Yoke
- □ 1 x Remote Contol
- □ 1 x AB Mount Plate (Attached)
- \Box 1 x IB-BTE AB to V-Mount Adapter Plate



Getting Started

- 1. Connect the included AC Adapter to power the IFD576-SP light.
- 2. Turn the light on/off with the power switch.
- 3. Control the amount of light with the dimmer knob. Adjust the intensity of the light by turning the dimmer knob clock-wise to increase the intensity, and counter clock-wise to reduce it.
- 4. The IFD576-SP can also be powered by pro battery.



Specifications

Product Specs	
Beam Angle	30°
Build Material	Molded Heavy Duty Plastic
Color Temperature	5600K (±200K)
Control	Local Knob & Touchscreen
Cooling System	Passive Heat Sync
Dimensions	13.5" x 8.5" x 2.75"
Dimming	10-100%
Focusing	NO
Head Type	Daylight
Lens	30°
Light Source	576 0.06 watt LED @ 5600K
Mount	Yoke
Operating Volts	12-24v
Power Supply	12v @3.33 Amps
Rating	120v @ 60Hrz
Weight	5 lbs
Shipping Weight	8 lbs
Shipping Dimensions	14" x 18" x 5"



Remote Control Button Functions


Press & hold "A" for 5 seconds to sync remote control to light. Press "A" to power ON/OFF Press "B" to adjust 4 levels of light intensity in increments of 25% Press & hold "B" for 5 seconds to enable/disable sound Hold down "C" to increase light intensity 0%-100% Hold down "D" to decrease light intensity 100%-0%



Optional Accessories

IB-L130A AB-Mount Professional Battery IB-L130S V-Mount Professional Battery IB-LD160 A IB-LD160 S C-2KA-KIT C-2KS-KIT

Connecting AB-Mount to V-Mount



Learn More

More dynamic information at official website: www.ikancorp.com

Support

Contact email: support@ikancorp.com

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period is expired.

Free Service will not be Provided in the Following Situations: (*Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors, etc.

©2015 ikan Coporation. All rights reserved