



# OTTICA


## FIRMWARE UPDATE GUIDE

### CONNECTION GUIDE


1. Plug in the 12v power supply to your OTTICA Controller.
2. Connect the USB micro cable to a USB port on your PC




Step 1: After extracting the .zip file from our product page, open the application “Stmlsp” in the “Keyboard Upgrade Tools” folder




Step 2: Click the drop-down button to select the port of your OTTICA controller.




Step 3: Click the icon with the 3 dots. This will open up a new browser window.




Step 4: Select the OTT-CONTROLLER-V2 firmware. It will be a .hex file.



Step 5: Click the “Open” button.



Step 6: Click the “Upgrade” button.



Allow the firmware to update. You can track the progress on the bottom section of the Stmlsp software. After the firmware finishes updating, the OTTICA controller will automatically restart. Unplug the USB cable from the upgrade port and you will be ready to use the controller with the new firmware.

## Learn More

More dynamic information at official website: [www.ikancorp.com](http://www.ikancorp.com)

## Support

Contact email: [support@ikancorp.com](mailto:support@ikancorp.com)

**ikan**  
**OTTICA**

©2023 Ikan International. All rights reserved.

