### PBK-A-C

## Pro Battery Adapter Kit for Anton Bauer w/ Coax P-Tap QUICKSTART GUIDE



# Checked by

#### What's included

	M-A	Battery	Plate
_			

Pro Adapter Plate

☐ 4 x M4x.07 x 8mm Metric Socket Head Screw

Hex Key

Coax to Power Tap Cable

#### CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\* Even if the product is still within the warranty period.)


- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.




## Pro Battery Adapter Kit for Anton Bauer w/ Coax P-Tap QUICKSTART GUIDE

#### Connect the Power Tab Cable to the VX7 monitor.

Remove the Phillips Head Screws to disassemble the M-A Battery Plate and the Pro Adapter Plate.




Install the M-A Battery Plate on to the VX7 monitor with the Phillips Head Screws.





## Pro Battery Adapter Kit for Anton Bauer w/ Coax P-Tap QUICKSTART GUIDE

#### Connect the Power Tab Cable to the VX9 monitor.



Attach the Pro Battery Plate to the VX9 monitor with four M4X.07 20mm Bolts.

