
# **VXPBK-A**

## (VX Series Pro Battery Kit) QUICKSTART GUIDE




### CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.







# **VXPBK-A**

## (VX Series Pro Battery Kit) QUICKSTART GUIDE

### Connect the Power Tab Cable to the VX9 monitor.




Attach the Pro Battery Plate to the VX9 monitor with four M4X.07 20mm Bolts.




#### NOTE:

Please make sure to insert the 'D-tap Connector' correctly into the battery plate to insure the proper polarity ("D"shape of the D-tap cable to the "D" shape of the battery adapter [See diagram]). Failure to do so may result in damage to the battery plate and/or to the product or products connected to the battery plate. The ikan Corporation takes no responsibility for damage to any product occurring as a result of the incorrect insertion of the D-Tap Connector to the battery plate.

## Connect the Power Tab Cable to the VX7 monitor.



Remove the Phillips Head Screws to disassemble the M-A Battery Plate and the Pro Adapter Plate.



Install the M-A Battery Plate on to the VX7 monitor with the Phillips Head Screws.

\* Please note that due to varying manufacturing tolerances and differing manufacturer's charging circuitry, it is recommend that ikan professional batteries only be used with ikan professional chargers/plates.



www.ikancorp.com 713-272-8822