


iLED-ONE

On Camera L.E.D. Light QUICKSTART GUIDE

- 1 Squeeze retaining clip by using pliers
- 2 Pull the L.E.D. bulb out of the body of the light
- 3 Detach the bulb from the base
- 4 Reverse the order for installing a new light

*** Retainer clip is under tension. To prevent bodily injury or damage to objects, use caution when removing or replacing the retainer clip.



Warning:

- Use caution when removing bulb retainer clip.
- For L.E.D. bulbs only. NOT for use with halogen bulbs.
- Do not block the vents or look directly at the LED light while its on.
- The body of the light might get hot, after prolong use.

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.