


RECOIL

Camera Stabilization QUICKSTART GUIDE



Whats included


- Recoil Body
- Long Baseplate
- Short Riser Baseplate
- Grip Bar
- Long Thumb Screw
- 2 x Cork Strips

Checked by

RECOIL

Camera Stabilization QUICKSTART GUIDE

For smaller cameras, the Short Riser Baseplate and Grip Bar can be added as shown.



Canon DSLR camera mounted on the Short Riser Baseplate with Grip Bar.

RECOIL

Camera Stabilization QUICKSTART GUIDE

Larger cameras can be utilized with either the Short Riser Baseplate or the Long Baseplate. Some camera may need a small washer to completely snug the camera to the Long Baseplate.



Panasonic camera mounted on the Long Baseplate.
(For certain Panasonic cameras the included camera screw may be too long to properly hold the camera. For this reason we have included two strips of cork to place on the recoil base to lift the camera to the proper height.)



Canon camera mounted on the Short Riser Baseplate.

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (*** Even if the product is still within the warranty period.*)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.

ikan

www.ikancorp.com

713-272-8822