

Ikan Tally Interface for AV Matrix S8X



Installation Guide

Package Contents

- 1x Tally Interface unit
- 1x Connection cable

Setup Instructions

AV Matrix Connection

1. Locate the Tally output port on your AV Matrix Switcher
2. Connect the included cable from the AV Matrix switcher's Tally port to the Ikan tally interface's input port.

Monitor Connections

1. Connect your Ikan monitors using standard Ethernet cables
2. Up to 4 monitors can be connected to the RJ45 output ports

Operation

- The system operates in plug-and-play mode with no additional configuration required
- When a camera is selected on the AV Matrix switcher, the corresponding monitor's tally light will illuminate red for Program

Important Notes

- Use only standard Ethernet cables for monitor connections
- Ensure all connections are secure before operation
- Only supports program (red) tally light functionality

For technical support, contact Ikan at 713.272.8822