

# MPA70

## QUICKSTART GUIDE

5-Section Lightweight Aluminum Monopod for Photo & Video



### What's Included

- 1 x MPA70 Monopod
- 1 x Carrying Case
- 1 x 1/8" Hex Key

<b>CHECKED BY</b>

ikan

[www.ikancorp.com](http://www.ikancorp.com)

[support@ikancorp.com](mailto:support@ikancorp.com)

713.272.8822

© 2017 ikan Corporation. All rights Reserved

Ikan and all affiliated companies hereby disclaim any and all liabilities for property, equipment, building and electrical damages, injuries to any persons, and direct or indirect economic loss associated with the use or reliance of any information contained within this document, and/or as a result of the improper, unsafe, insufficient and negligent assembly, installation, rigging and operation of this product.

# Introduction

The MPA70 features a dual-sided mounting screw with a 1/4-20 and 3/8-16 thread and 4 twist-lock knobs used to extend or contract the monopod height.

## How to Change Screw Thread

The MPA70 comes pre-assembled with the dual-sided mounting screw set to 3/8-16. To flip the screw over to 1/4-20 use the following steps:


**Step 1:** To remove the circular base loosen the lock screw located next to the 3/8-16 screw. Use the provided 1/8" hex key and rotate the screw counter-clockwise just enough until it becomes loose.

**Step 2:** While looking down at the monopod, grab and twist the circular base in a counter-clockwise direction. Continue to twist the base until it is detached from the monopod.

**Step 3:** Remove the mounting screw from inside the base, flip over to the 1/4-20 side, and reinsert the screw back into the center of the base.

**Step 4:** Screw the circular base back on to the monopod by rotating it in a clockwise fashion. Firmly tighten the base with your hand until secure.

**Step 5:** Finish securing the circular base to the monopod by tightening the lock screw with the provided 1/8" hex key.



## Operating the Twist-Lock

The MPA70 features 4 twist-lock knobs that divide the monopod into 5 sections. To adjust the height of the monopod, use the following steps:

- Step 1: While looking down at the monopod, grab the desired knob with your hand, and twist the knob clockwise to open it.
- Step 2: Adjust the height of the monopod by raising or lowering the open section.
- Step 3: Once you have found your desired height, grab the open knob with your hand, and twist the knob counterclockwise until it is firmly locked in place.

Repeat steps 1-3 for each additional section.



# Specifications

Fixture Specifications	
Weight	1.59 lbs
Minimum Height	18.8 in.
Maximum Height	70.8 in.
Leg Tube Diameter	0.87 - 1.35 in.
Upper Disc Diameter	2.3 in.
Vertical Payload Weight	35 lbs
Horizontal Payload Weight	7 lbs
Leg Sections	5
Top Attachment	3/8"-16 and 1/4"-20
Leg Lock Type	Twist Lock
Material	Aluminum

\* Do not exceed the payload weight when the monopod is extended out away from your body. Neglecting to follow this warning may result in structural failure of the MPA70 monopod.

## Optional Accessories

Some other products that work well with the MPA70 Monopod available from Ikan include:

<b>VL35</b>	3.5" 4K Signal Support HDMI On-Camera Field LCD Monitor with Canon LP-E6 Battery Plate
<b>EC1</b>	EC1 Beholder 3-Axis Gimbal Stabilizer with Encoders
<b>MS-PRO</b>	MS-PRO Beholder 3-Axis Gimbal Stabilizer with Encoders
<b>HDMI-AC1.4</b>	Slim HDMI Cable with v1.4 Ultra HD 4K Support ( <i>Mini to Standard</i> )
<b>HDMI-AD1.4</b>	Slim HDMI Cable with v1.4 Ultra HD 4K Support ( <i>Micro to Standard</i> )
<b>ELE-PN</b>	Pinch Clamp
<b>EI-A49</b>	5" Articulating Monitor Arm (E-Image)
<b>DGH</b>	Dual Grip Handle & Tray for EC1, & MS-PRO

## **Learn More**

More dynamic information at official website: [www.ikancorp.com](http://www.ikancorp.com)

## **Support**

Contact email: [support@ikancorp.com](mailto:support@ikancorp.com)

### **CONDITIONS OF WARRANTY SERVICE**

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period is expired.

Free Service will not be Provided in the Following Situations:(\*Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors, etc.