

## INTRODUCTION

Please open the box and make sure nothing has been damaged in shipment. If damage is apparent please contact the ikan customer support department at 713-272-8822 or support@ikancorp.com.

Thank you for purchasing the ikan Uni-Rack 2/5 portable desktop rack-mount system. We know that you will be extremely pleased with its versatility and ease of use. If you would like more information on our full line of current and up-coming products please visit our website at: www.ikancorp.com, or call us at 713-272-8822.

## PACKAGE CHECK LIST

### UNI-RACK 2:

- Uni-Rack 2 portable Desktop rack-mount system consisting of left and right Uni-Rack ears.
- A set of 4 cage-nuts and 4 rack screws for the Uni-Rack 2
- A set of 8 self-adhesive rubber feet for attaching to the left and right Uni-Rack ears.

\_\_\_\_\_  
Checked by

### OR


### UNI-RACK 5:

- Uni-Rack 5 portable Desktop rack-mount system consisting of left and right Uni-Rack ears.
- A set of 8 cage-nuts and 8 rack screws for the Uni-Rack 5.
- A set of 8 self-adhesive rubber feet for attaching to the left and right Uni-Rack ears.

\_\_\_\_\_  
Checked by

## GETTING STARTED

1. Remove the left and right Uni-Rack ears from the box and attach the rubber self-adhesive feet on each bottom corner of the 2 pieces as per diagram 1A. The rubber feet help hold your equipment in place and will prevent scratching your desktop.
2. After determining the appropriate position for your rack-mountable equipment carefully attach the included cage nuts to the rack-ear opening as per diagram 2A. The larger portion of the cage nuts slide in behind the front of the left and right Uni-rack ears.
3. Using the included rack screws attach your equipment making sure the screws are tight. Make sure the equipment is balanced properly before placing it on your desktop.



## CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- A maintenance service fee plus parts will be charged if the warranty period has expired.

### Free Service will not be Provided in the Following Situations:

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company. \*
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc. \*

\* Even if the product is still within the warranty period.