IFD2115

Featherweight Kit w/ 2x IFD1024 & 1x IFD576 w/ AB & V-Mount Plates

QUICK START GUIDE



What's Included

- □ 1 x IFD576 LED Light
- □ 2 x IFD1024 LED Lights
- □ 3 x HD Stands
- □ 1 x IBG-1000-3L
- □ 1 x Stand Bag

Additional Quickstart Guides

- ☐ IFD576 LED Light QSG
- ☐ IFD1024 LED Light QSG





FD576

576 Featherweight Daylight LED Light

QUICK START GUIDE



What's Included

- □ 1 x IFD576
- □ 1 X AC Adapter + Power Cord
- ☐ 1 x Remote Control
- □ 1 x Yoke
- □ 1 x Diffuser
- □ 1 x AB Mount Plate (Attached)
- \Box 1 x AB to V-Mount Adapter






IFD576

Getting Started

- 1. Connect the included AC Adapter to power the IFD576 light.
- 2. Turn the light on/off with the power switch.
- 3. Control the amount of light with the dimmer knob. Adjust the intensity of the light by turning the dimmer knob clock-wise to increase the intensity, and counter clock-wise to reduce it.
- 4. The IFD576 can also be powered by pro battery.



Specifications

Product Specs	
Beam Angle	60°
Build Material	Heavy Duty Plastic
Control	Local Knob & Touchscreen
Cooling System	Passive Cooling
Dimensions	13.5" x 8.5" x 2.75"
Dimming	0-100%
Focusing	NO
Foot Candles	520.6
Head Type	Daylight
Lens	60° Lens
Light Source	576 0.06 watt LED @5600K
Mount	Yoke
Operating Volts	12-24v
Power Supply	12v @ 3.33 Amps
Rating	120v @ 60 Hrz
Yoke	60°
Fixture Size	14" x 8.5" x 2.75"
Fixture Weight	4 lbs
Shipping Weight	7 lbs



Remote Control Button Functions

Press & hold "A" for 5 seconds to sync remote control to light.

Press "A" to power ON/OFF

Press "B" to adjust 4 levels of light intensity in increments of 25%

Press & hold "B" for 5 seconds to enable/disable sound

Hold down "C" to increase light intensity 0%-100%


Hold down "D" to decrease light intensity 100%-0%



Optional Accessories

IB-L130A AB-Mount Professional Battery IB-L130S V-Mount Professional Battery IB-LD160 A IB-LD160 S C-2KA-KIT C-2KS-KIT

Connecting AB-Mount to V-Mount



IFD1024

1024 Featherweight Daylight LED Light

QUICK START GUIDE



What's Included


- □ 1 x IFD1024
- □ 1 x AC Adapter + Power Cord
- □ 1 x Remote Control
- □ 1 x Yoke
- □ 1 x Diffuser
- □ 1 x AB Mount Plate (Attached)
- \Box 1 x IB-BTE AB to V-Mount Adapter Plate





Getting Started

- 1. Connect the included AC Adapter to power the IFD1024 light.
- 2. Turn the light on/off with the power switch.
- 3. Control the amount of light with the dimmer knob. Adjust the intensity of the light by turning the dimmer knob clock-wise to increase the intensity, and counter clock-wise to reduce it.
- 4. The IFD1024 can also be powered by pro battery.



Specifications

Product Specs	
Beam Angle	60°
Build Material	Heavy Duty Plastic
Color Temperature	5600(±100)
Control	Local Knob Control & Touchscreen
Cooling System	Passive Cooling
Dimensions	17" x 14" x 3.75"
Dimming	43.18 x 35.56 x 9.53 cm
Fixture Size	14" x 14" x 2.75"
Focusing	NO
Foot Candles	979.8
Head Type	Daylight
Lens	60° Lens
Light Source	1024 0.06watt LED @ 5600K
Mount	Yoke
Power Supply	12v @ 6.66 Amps
Rating	120v @ 60Hrz
Fixture Weight	6 lbs
Shipping Weight	10 lbs



Remote Control Button Functions

Press & hold "A" for 5 seconds to sync remote control to light.

Press "A" to power ON/OFF

Press "B" to adjust 4 levels of light intensity in increments of 25%

Press & hold "B" for 5 seconds to enable/disable sound

Hold down "C" to increase light intensity 0%-100%


Hold down "D" to decrease light intensity 100%-0%



Optional Accessories

IB-L130A AB-Mount Professional Battery IB-L130S V-Mount Professional Battery IB-LD160 A IB-LD160 S C-2KA-KIT C-2KS-KIT

Connecting AB-Mount to V-Mount



Learn More

More dynamic information at official website: www.ikancorp.com

Support

Contact email: support@ikancorp.com

CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period is expired.

Free Service will not be Provided in the Following Situations: (*Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors, etc.