# PT15-T | Quick Start Guide



15" High Bright SDI Teleprompter LED Monitor w/ Tally



### What's Included

- ☐ 1 x Teleprompter Monitor w/ Tally
- ☐ 1 x Power Adapter











### **Monitor Input Ports**



SDI – BNC Connection AV – Composite BNC Connection VGA – DE15 Connection

HDMI - High-Definition Multimedia Interface Input Connection

12 - 24V - Threaded Barrel Power Input



HDMI - Switch HDMI input

VGA – Switch to VGA input

VGA – Switch to VGA input

AV — Switch to Composite input

Flip – Toggle image flip

(Can be set to horizontal, vertical, or both via menu)

Up Arrow – Toggle up to adjust setting

Menu – Access to monitor settings

Down Arrow – Toggle down to adjust setting

### **Monitor Menu Settings**

Video Config

Contrast (White Level)

Brightness (Black Level)

Tint (Chroma Hue)

Chroma (Chroma Saturation)

Sharpness (Detail)

RGB Setup - Manually configure RGB

Return

System Config

Menu Duration – Set duration of how long menu stays on screen

Video Ratio – Set screen aspect ratio 16:9 or 4:3 (4:3 is native resolution, 16:9 will create black bars)

Flip-H — Assign toggle button to flip image horizontally

Flip-V – Assign toggle button to flip image vertically

Reset – Factory reset

Return

PC Setup (Only available for VGA)

H-Position – Adjust horizontal position

V-Position – Adjust vertical position

 $\label{eq:automatically} \text{Auto} - \text{Monitor automatically adjust position}$ 

Return

Fxit

### How to set-up FLIP button feature:

- 1. Press MENU button
- 2. Navigate to SYSTEM CONFIG.
- 3. Navigate to FLIP-V or FLIP-H
- 4. Change FLIP-V and/or FLIP-H to "ON"
- 5. Exit MENU
- 6. The FLIP button should now be activated and can be pressed to mirror the image Horizontally or Vertically
- 7. When FLIP-H is ON, the image will flip Horizontally
- 8. When FLIP-V is ON, the image will flip Vertically
- 9. If both are ON, the FLIP button will toggle both Horizontal and Vertical flip









### **Specifications**

## **Supported Video Signals**

SDI

720x480i @ 59.94, 60 Hz 720x576i @ 50 Hz 1280x720p @ 50, 60 Hz 1920x1080i @ 50, 59.94, 60 Hz 1920x1080psf @ 24, 25, 29.97, 30 Hz 1920x1080p @ 23.98, 24, 25, 29.97, 30, 50, 59.94, 60 Hz

#### **HDMI**

720x480i & 720x480p @ 59.94, 60 Hz
720x576i & 720x576p @ 50 Hz
1280x720p @ 50, 59.94, 60 Hz
1920x1080i @ 50, 59.94, 60 Hz
1920x1080psf @ 24, 25, 29.97, 30 Hz
1920x1080p @ 23.98, 24, 25, 29.97, 30, 50, 59.94, 60 Hz








## **Pinout Diagram for Tally Light**

#### **Tally Light Pinout:**



### **Learn More**

More dynamic information at official website :www.ikancorp.com

## **Support**

Contact email: support@ikancorp.com

 $\hbox{@2025 Ikan International.All rights reserved}.$ 









### **Learn More**

More dynamic information at official website: www.ikancorp.com

## **Support**

Contact email: support@ikancorp.com

#### **CONDITIONS OF WARRANTY SERVICE**

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period is expired.

Free Service will not be Provided in the Following Situations: (\*Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors, etc.

©2025 Ikan International. All rights reserved.







